RIGID RESIN formlabs ₩

Rigid 4000

Resin for Stiff, Strong, Engineering-Grade Prototypes

Glass-filled Rigid 4000 Resin prints with a smooth, polished finish and is ideal for stiff and strong parts that can withstand minimal deflection. Consider Rigid 4000 Resin for general load-bearing applications.



Prepared 10.07.2020

Rev. 01 10.07.2020

To the best of our knowledge the information contained herein is accurate. However, Formlabs, Inc. makes no warranty, expressed or implied, regarding the accuracy of these results to be obtained from the use thereof.

	METRIC ¹		IMPERIAL 1		METHOD
	Green ²	Post-Cured ³	Green ²	Post-Cured ³	
Tensile Properties					
Ultimate Tensile Strength	33 MPa	69 MPa	4786 psi	10007 psi	ASTM D638-14
Tensile Modulus	2.1 GPa	4.1 GPa	305 ksi	595 ksi	ASTM D638-14
Elongation at Break	23%	5.3%	23%	5.3%	ASTM D638-14
Flexural Properties					
Flexural Stress at 5% Strain	43 MPa	105 MPa	6236 psi	15229 psi	ASTM D 790-15
Flexural Modulus	1.4 GPa	3.4 GPa	203 ksi	493 ksi	ASTM D 790-15
Impact Properties					
Notched Izod	16 J/m	23 J/m	0.3 ft-lbf/in	0.43 ft-lbf/in	ASTM D256-10
Thermal Properties					
Heat Deflection Temp. @ 1.8 MPa	41 °C	60 °C	105 °F	140 °F	ASTM D 648-16
Heat Deflection Temp. @ 0.45 MPa	48 °C	77 °C	118 °F	170 °F	ASTM D 648-16
Thermal Expansion (0-150 °C)	64 μm/m/°C	63 μm/m/°C	36 μin/in/°F	35 μin/in/°F	ASTM E 831-13

SOLVENT COMPATIBILITY

Percent weight gain over 24 hours for a printed and post-cured 1 x 1 x 1 cm cube immersed in respective solvent:

Solvent	24 hr weight gain, %	Solvent	24 hr weight gain, %
Acetic Acid 5%	0.8	Isooctane (aka gasoline)	< 0.1
Acetone	3.3	Mineral oil (light)	0.2
Isopropyl Alcohol	0.4	Mineral oil (Heavy)	0.2
Bleach ~5% NaOCI	0.7	Salt Water (3.5% NaCl)	0.7
Butyl Acetate	< 0.1	Sodium Hydroxide solution (0.025% PH 10)	0.7
Diesel Fuel	< 0.1	Water	0.7
Diethyl glycol Monomethyl Ether	1.4	Xylene	< 0.1
Hydraulic Oil	0.2	Strong Acid (HCI conc)	5.3
Skydrol 5	1.1		
Hydrogen peroxide (3%)	0.9		

additional treatments.

¹ Material properties can vary with part geometry, print orientation, print settings, and temperature.
2 Data was obtained from green parts, printed using Form 3, 100 µm, Rigid settings, without 3 Data was obtained from parts printed using Form 3, 100 µm, Rigid settings and post-cured with a Form Cure for 15 minutes at 80 °C.